

Rowan Rig 80 (EXL 1) Shear Procedure

To initiate the blind shear sequence (with the Shear Booster installed) the following steps shall be followed:

#1 shift high pressure bypass to 3,000 PSI

#2 Function blind rams delivering 3,000 PSI to blind/shear rams.

NOTE: This can be done from the Cameron unit under the cantilever, driller remote on the rig floor or tool pusher remote in wheel house.